

### Maintenance

Because of the design and the quality of the used materials, the **BL-45** does not require any special maintenance measures. It is however important to clean the barrier entirely after each usage prior to putting it into the storage room.

In case damages have occurred on the barrier, due to sharp edged foreign material, bad weather conditions and heavy seas, some maintenance works may be required. For minor repair works, needed advice is available.